

简体中文

便携高清无损音乐播放器

机器接口介绍 (图片仅供参考, 具体以实物为准)

3.5mm耳机/线路/同轴输出口

4.4mm平衡耳机/线路输出口

指示灯

显示屏

电源/锁屏键

音量加键

音量减键

多功能键

台机模式开关

HOLD开关

上一曲键

播放/暂停键

下一曲键

TF卡槽

Type-C数据/充电端口

1

简体中文

便携高清无损音乐播放器

开/关机

M21关机状态长按电源/锁屏键开机, 首次开机时, 选择相应语言, 点击完成进入主界面; 开机状态下长按电源/锁屏键出现关机提示框, 可选择关机或重启。

充电

M21底部的POWER IN端口支持PD协议快充, 为达到设计的充电时间, 推荐选用符合PD3.0或以上的充电器。

Type-C接口

M21底部有2个Type-C的USB端口, 标识USB3.0的端口, 支持数据传输/普通充电、USB HOST、USB OTG等功能; 标识POWER IN的端口, 仅支持充电/供电功能, 不能连接电脑传输数据。

手势操作

返回上一级: 从屏幕左侧边缘向右滑动或屏幕右侧边缘向左滑动  
返回桌面: 从屏幕下方上滑  
多任务管理: 从屏幕下方上滑并停留

工作模式切换

M21拥有5种工作模式, 分别为安卓模式、纯音模式、USB DAC模式、蓝牙接收模式、AirPlay模式, 首次开机将默认为安卓模式, 您可以在下拉菜单, 或设置菜单中点击工作模式来切换不同的工作模式。

● 安卓模式/纯音模式:

安卓模式/纯音模式下可连接电脑与M21传输数据。  
注: MAC系统的MTP驱动可通过下载地址:  
[https://www.fiio.com/Driver\\_Download](https://www.fiio.com/Driver_Download)进行下载。

2

简体中文

便携高清无损音乐播放器

● USB解码模式:

首次使用USB解码模式前, 您需要前往官网下载USB DAC驱动, 并按照相应教程安装驱动后方可使用USB解码功能。

● 蓝牙接收模式:

首次切换到蓝牙接收模式时, M21将自动进入配对状态, 后续再次进入蓝牙接收模式时将自动回连上一次连接设备。

● 本地升级

● AirPlay模式:

3

简体中文

便携高清无损音乐播放器

固件升级

● OTA在线升级

打开WiFi并连接到可用网络即可自动检测是否有新版本固件更新。若未检测到新版本, 可尝试前往“技术支持-固件升级-在线升级”, 点击“检查更新”进行手动检测更新。

● 本地升级

请前往官网下载升级固件, 并按相应教程进行版本升级。  
下载地址: <http://www.fiio.com/supports>

注意事项

★请勿将电池置于高温环境中, 电池浸水后禁止使用, 若出现鼓胀, 请勿继续使用。禁止拆解、撞击、挤压、刺破电池或将电池投入火中。  
★请勿将设备置于温度过高或过低 (45°C以上0°C以下), 请勿将设备放置在车内存等密闭高温环境中。  
★不可自行维修、拆卸并将产品放在有水的地方。  
★当长期没有使用本产品时, 需要定期给产品充电, 以保证电池寿命。  
★当您在使用耳机时, 会因此听不清外界环境声音, 为了您的安全, 请避免在危险环境中使用耳机。  
★搭配电压过高的充电器适配器充电可能会损坏机器, 请选择推荐使用的充电器进行充电。  
★系统发生故障导致死机时, 可尝试长按“电源/锁屏键”10秒以上, 强制重启机器。

包装清单

(请核对包装内是否包括以下物品)

● M21主机

● 主机保护套

● 售后维修卡

● 镜片保护膜 (出厂贴在主机上)

● USB数据线

● 快速入门

5

简体中文

便携高清无损音乐播放器

了解更多

● 有关M21的相关视频说明和常见问题解答 (FAQ), 请扫描M21 FAQ二维码。  
● 了解产品更多信息请访问: [www.fiio.com](http://www.fiio.com)  
● 了解产品详细使用说明请访问<https://www.fiio.com/supports> 下载相关文件查阅。  
● 在M21的“设置-系统-法律信息”中, 可以查看产品的CMIIT-ID

产品名称: 便携高清无损音乐播放器  
产品型号: F3071M  
额定输入: 5V=2A  
尺寸: 约68x121x17mm  
重量: 约193g  
执行标准: Q/FADZ 1-2017  
制造厂: 广州飞傲电子科技有限公司  
地址: 广州市白云区龙归街夏良龙良路21号

由于产品不断改进, 各项规格及设计随时更改, 恕不另行通知。

6

English

Portable High Resolution Music Player

Buttons and Ports Labeled

(Pictures are for reference only. The actual product may vary)

3.5mm headphone out/line out/coaxial out

4.4mm balanced headphone out/line out

Indicator light

Display

Power/Lock button

Volume up

Volume down

Multifunction button

Desktop mode switch

HOLD switch

Previous track

Play/Pause

Next track

Type-C charging/power supply port

microSD card slot

Type-C data/charging port

7

English

Portable High Resolution Music Player

Power On/Off

Hold the Power/Lock button to turn on the M21 while it is off. On its first startup, tap the preferred language onscreen to enter the main UI. Hold the Power/Lock button while the M21 is on and a shutdown dialogue will pop up. You can select to turn off or reboot the player.

Charging

The bottom POWER IN port supports PD fast charging protocol. To achieve the designed charging time, it is recommended to use a PD3.0 or above power source.

Type-C Port

The bottom of the M21 has two Type-C ports. The one marked USB3.0 supports data transfer, common charging, USB HOST, USB OTG and so on. The other marked POWER IN only supports charging/power supply but not data transfer with computers.

Gesture Operation

Return to previous menu: Swipe right from the left edge of the screen, or swipe left from the right edge.  
Return to homepage: Swipe up from the bottom edge of the screen.  
Multitask managing: Swipe up from the bottom edge of the screen and then hold.

Working Modes Switch

The M21 has five working modes: Android mode, Pure Music mode, USB DAC mode, Bluetooth Receiving mode, and AirPlay mode. The M21 will default to enter Android mode when it powers on for the first time. You can switch to other working modes on the drop-down or Settings menu.

8

English

Portable High Resolution Music Player

● Android mode/Pure Music mode

Under the Android mode/Pure Music mode, the M21 can be connected to a computer for data transmission.  
Note: The MTP driver for macOS can be downloaded via the following link: [https://www.fiio.com/Driver\\_Download](https://www.fiio.com/Driver_Download).

● USB DAC mode

Before using the USB decoding mode for the first time, please visit our official website to download the USB DAC driver. Follow relevant instructions to install the driver before using the USB DAC function.

● Bluetooth Receiving mode

When switching to the Bluetooth Receiving mode for the first time, the M21 will automatically enter the pairing state. The next time it enters Bluetooth Receiving mode, it will reconnect to the last connected device automatically.

● AirPlay mode

The AirPlay mode requires a valid WIFI connection. Please confirm that the M21 is connected to an available network before entering the AirPlay mode.

Desktop Mode Switch (D.MODE)

When switching to ON, the desktop mode is enabled, and the battery will not be charged; when switching to OFF, the desktop mode is disabled, and the battery will be charged.

9

English

Portable High Resolution Music Player

HOLD Switch

After the HOLD switch is enabled, the side buttons of the M21 will be locked to prevent unintended touches. You can select which buttons to lock in the settings menu or restore the button functionality by disabling the HOLD switch.

Super High Gain Mode

When a fast-charging power adapter is inserted in the M21 and is detected, the "Super High Gain mode" will show up on the GAIN settings menu. If the D.MODE switch is set to ON, a dialogue prompt of "Switch to Super High Gain mode?" will pop up, and you can decide whether to switch based on your needs or not.

Firmware Upgrade

● OTA (Over-the-Air) online upgrade

Turn on the WiFi function on the M21 and connect it to an available network. It will automatically detect if there is a new firmware. If no firmware is detected, please go to "Technical Support -> Firmware Update -> Online Upgrade" to check and upgrade the firmware manually.

● Local upgrade

Please download the firmware on our website and follow relevant instructions to upgrade it.  
Download link: <http://www.fiio.com/supports>

10

English

Portable High Resolution Music Player

Notes and Precautions

★Please do not put the battery in a high-temperature environment. The battery is prohibited from use if it is soaked in water, or if it gets swollen. Please do not disassemble, hit, crush, or puncture the battery, and do not put it on fire.  
★Please do not place the device in circumstances of excessive high/low temperatures (above 45°C or below 0°C), or in an enclosed high-temperature environment, such as in a car.  
★Please do not repair or disassemble the device on your own and do not put it in water.  
★Please charge the battery on a regular basis to secure the battery life if this device has not been used for a long time.  
★You might not be able to hear the sound of the surroundings when using headphones. For your safety, please avoid using headphones in dangerous situations.  
★It is recommended to use a suitable charger in case of a high-voltage adapter causing damage to the device.  
★In the likely event that the M21 hangs up, you may hold the "Power/Lock button" for over 10 seconds to force a reboot.

List of Items Included

(please check if the following items are included)

● M21

● Screen protector (applied on the M21 in factory)

● Protective case

● USB data cable

● Warranty card

● Quick start guide

11

English

Portable High Resolution Music Player

To Learn More

● For related video instructions of the M21 and FAQ (Frequently Asked Questions), please scan the QR code below.  
● To learn more about the product, please visit our website: [www.fiio.com](http://www.fiio.com)  
● For detailed instructions of the M21, please visit <https://www.fiio.com/supports>  
● To check the CMIIT-ID of the M21, please go to the menu of Settings->System->Legal information.

Due to continuous improvement, every specification and design is subject to change at any time without further notice.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be handed as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.  
Internal/Supplied Batteries:  
This symbol on the battery indicates that the battery is to be collected separately. This battery is designed for separate collection at an appropriate collection point.

12

English

Portable High Resolution Music Player

Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries.

Qualcomm aptX HD

Hereby, Guangzhou FIO Electronics Technology Co., Ltd declares that this device is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at: [www.fiio.com/doc](http://www.fiio.com/doc)

Function	Frequency	Maximum output power
Bluetooth	2402-2480MHz	6dBm
	2412-2472MHz	15dBm
WiFi	5180-5320MHz	13dBm
	5500-5825MHz	12dBm

For this radio device, the following restrictions on putting into service or of requirements for authorisation of use apply in BE, BG, CZ, DK, DE, EE, IE, EL, ES, FR, HR, IT, CY, LV, LT, LU, HU, MT, NL, AT, PL, PT, RO, SI, SK, FI, SE, UK, IS, LI, NO, CH, TR: 5150-5350 MHz band is restricted to indoor operations only.

13

English

Portable High Resolution Music Player

FCC NOTICE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
•Reorient or relocate the receiving antenna.  
•Increase the separation between the equipment and receiver.  
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
•Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

14