




快速入门指南 Quick Start Guide

ECHO

接口说明



- 1.电源键: 开关机, 亮屏/熄屏
- 2.音量+按键: 上一曲, 音量加, 切换菜单
- 3.音量- 按键: 下一曲, 音量减, 切换菜单
- 4.播放/暂停键: 播放/暂停, 操作确认
- 5.菜单键: 进入菜单设置
- 6.返回键: 返回上一级操作
- 7.TF卡槽: 存放TF卡
- 8.Type-C USB口: 充电/数据传输
- 9.挂绳孔
- 10.显示屏
- 11.复位孔
- 12.3.5mm单端耳机输出端口
- 13.4.4mm平衡耳机输出端口

功能操作说明

开关机: 长按电源键3S开关机。

调节音量: 播放状态页面下短按音量键进行音量调节。

音乐换曲: 长按音量键进行切曲操作。

播放/暂停: 短按播放/暂停键进行播放暂停操作。

返回操作: 短按返回键, 返回上一级操作。

删除操作: 进入文件浏览, 选择歌曲后短按菜单键, 会跳出提示窗口进行删除操作。

菜单切换选择: 菜单界面短按音量键切换菜单选项, 短按播放/暂停键选择确认。

蓝牙开关: 系统设置里打开蓝牙开关, 通过蓝牙搜索可以连接蓝牙耳机等设备。

菜单页面

文件浏览: 查看本机文件和TF卡文件的内存和资料。

播放列表: 音乐的媒体库, 可以找到分类后的文件和歌曲。

音乐播放: 进入音乐播放页面。

阅读: 可以进行电子书等文件的阅读。

音乐设置: 设置音乐的循环模式, 音量限制, EQ选择以及滤波器等功能。

系统设置: 系统设置, 可以设置系统语言, 屏幕开关时间等功能。

注意事项

- ★请勿将电池置于高温环境中, 电池浸水后禁止使用, 若出现鼓胀, 请勿继续使用。禁止拆解、撞击、挤压、刺破电池或将电池投入火中。
- ★请勿将设备置于温度过高或过低(45°C以上0°C以下), 请勿将设备放置在车内等密闭高温环境中。
- ★请勿使用错误型号的电池组替换, 以防止有着火或爆炸。
- ★不可自行维修、拆卸和将产品放在有水的地方。

- ★当长期没有使用本产品时, 需要定期给产品充电, 以保证电池寿命。
- ★当您在使用耳机时, 会因此听不清外界环境声音, 为了您的安全, 请避免在危险环境中使用耳机。
- ★搭配电压过高或过低的充电适配器充电可能会损坏机器, 请选择推荐使用的充电器进行充电。
- ★系统发生故障导致死机时, 可尝试拿卡针轻按“复位孔”进行复位, 并强制重启机器。

了解更多

- 1.了解产品详细使用说明请访问:
<http://www.fiio.com/supports>
- 2.欢迎扫描二维码访问:



飞傲官方网站



飞傲官方公众号

- 由于产品不断改进, 各项规格及设计随时更改, 恕不另行通知。

环保材料说明


部件名称	产品中有害物质的名称及含量					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr,VI)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB	X	0	0	0	0	0
PCBA 焊点	X	0	0	0	0	0
元器件	X	0	0	0	0	0
显示屏*	X	0	0	0	0	0
电池*	X	0	0	0	0	0
外观件	0	0	0	0	0	0
配件*	X	0	0	0	0	0

注: 表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。带*号部件表示如果在您所购买的产品中无该部件, 请忽略表中该部件信息。
0: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572-2011规定的限量要求以下。
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572-2011规定的限量要求。

根据中国电子行业标准SJ/T 11364-2014 和相关的中国政府法规, 本产品及其某些内部或外部组件上可能带有环保使用期限标识。取决于组件和组件制造商, 产品及其组件上的使用期限标识可能有所不同。组件上的使用期限标识优先于产品上任何与之相冲突的或不同的环保使用期限标识。

此环保使用期限只适用于产品在规定的条件下工作

Buttons and ports labeled



1. Power button: Power on/off, Turn on/off display
2. Volume+: Previous track, Volume up, Switch submenu
3. Volume-: Next track, Volume down, Switch submenu
4. Play/Pause: Play/Pause, Confirm
5. Menu: Enter settings menu
6. Return: Return to previous operation
7. microSD card slot: Store microSD card
8. USB Type-C port: Charging/Data transfer
9. Lanyard hole
10. Display
11. Reset hole
12. 3.5mm SE headphone out
13. 4.4mm BAL headphone out

Operation function explained

Power on/off: Hold the Power button for about 3s to turn on/off the device.

Adjust volume: In the playback state, short press the volume buttons to adjust the volume.

Switch songs: Hold the volume buttons to switch songs.

Play/Pause: Short press the Play/Pause button to start or pause the playback.

Return: Short press the Return button to return to the previous operation.

Delete: In the file browser, selecting the song and short pressing the menu button will call up a prompt window with deletion.

Switch/Confirm menu: On the menu page, short press the volume buttons to switch submenus, and short press the Play/Pause button to confirm.

Bluetooth switch: Turn on the Bluetooth switch in system settings, and search through Bluetooth to connect to Bluetooth devices like Bluetooth headphones.

Menu page

File browser: Check files in the local storage and microSD card.

Playlist: Music library, classified files and songs can be found.

Music playing: Enter the music playing page.

Reading: Supports reading e-books and other document files.

Music settings: Set the music loop mode, volume limit, EQ style, filter type, and other functions.

Settings: System settings, supports settings of system language, screen on/off timer, etc.

Notes and precautions

★Please do not put the battery in a high-temperature environment. The battery is prohibited from use if it is soaked in water, or if it gets swollen. Please do not disassemble, hit, crush, or puncture the battery, and do not put it on fire.

★Please do not place the device in circumstances of excessive high/low temperatures (above 45°C or below 0°C), or in an enclosed high-temperature environment, such as in a car.

★Please do not replace with an incorrect battery pack model to avoid the risk of fire or explosion.

★Please do not repair or disassemble the product on your own and do not put it near water.

★Please charge the battery on a regular basis to secure the battery life if this product has not been used for a long time.

★You might not be able to hear the sound of the surroundings when using headphones. For your safety, please avoid using headphones in dangerous situations.

★It is recommended to use a suitable charger in case of a high-voltage adapter causing damage to the device.

★In the unlikely event that the device hangs up, please try to use an ejector pin to gently press the “Reset hole” to reset it, and then force a reboot.

To learn more

1. To learn more about the product, please visit our website:
<http://www.fiio.com/supports>
2. Scan the QR code to visit:



FIIO website



FIIO facebook

- Note: Due to continuous improvement, each specification and design is subject to change at any time without further notice.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be handed as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Internal/Supplied Batteries:

This symbol on the battery indicates that the battery is to be collected separately. This battery is designed for separate collection at an appropriate collection point.

Hereby, Guangzhou FIIO Electronics Technology Co., Ltd declares that this device is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at: www.fiio.com/doc

Function	Frequency	Maximum output power
Bluetooth	2400-2483.5MHz	20.0dBm



FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

广州飞傲电子科技有限公司
Guangzhou FIIO Electronics Technology Co., Ltd.